



Item	Description	Part Number
1	3/8 - 16 x 5/8" socket head cap screw (4)	999-14-004
2	Bearing D55510ND (2)	693-08-202
3	Seal	693-08-203
4	Cylinder	693-08-204
5	Lubrication ports (2)	
5a	10x32 fitting for 5/32 hose	693-02-001
5b	1/4x28 fitting for 5/32 hose	997-05-005
6	Snap ring (2)	693-08-206
7	Main bearing housing	693-08-207
8	Quad Ring A	693-08-208
9	Knurl adjust knob	693-08-209
10	Draw tube lock	693-08-210
11	Draw Tube	693-08-211
12	Main Bearing Mt	693-08-212
13	Snap ring (2)	693-08-213
14	Quad ring B	693-08-214
15	O ring A	693-08-215
16	Air ports (2) - Air fitting 1/4"	997-05-001
17	Piston	693-08-217
18	O ring B	693-08-218
19	Set Screw, 1/4"-20 x .375, Brass tipped	999-14-005