



Notes: Use F2 key to access bios screen.

Remove Jumper JB10 when using monochrome monitor and video card.

When using an LCD monitor, do not remove JB10 Jumper.

Add on board video cable to location number 3.



1. Keyboard
2. Power Supply
3. VGA Cable (if using LCD screen)
4. JB10 Jumper
5. Hard Drive
6. Floppy Drive